

GR-USB/EPSONプリンタ対応機種(2009/8/28現在)

※赤字の機種は特注での対応となります。

	日本	北米	欧州	中国
フォトプリンタ	E-200 E-150 E-300 E-500 E-700 E-300L E-520 E-720 E-530P E-530C E-530S E-330	PictureMate Deluxe PictureMate PM 200 PictureMate PM 240 PictureMate PM 280 PictureMate PM 260 PictureMate PM 290	PictureMate 500 PictureMate 100 PictureMate PM 240 PictureMate PM 280 PictureMate PM 260 PictureMate PM 290	PictureMate 500 PictureMate PM 210 PictureMate PM 310
スタンダードアロン	PM-D800 PM-D600 PM-G730 PX-G930 PM-D870 PM-G850 PX-V630 PM-G860 PX-V780 EP-301 PX-201 PX-101	EPSON STYLUS PHOTO R340 EPSON Stylus C68 EPSON STYLUS PHOTO R220 EPSON STYLUS PHOTO R380 EPSON STYLUS Photo R260 EPSON STYLUS C88 EPSON STYLUS C88+ EPSON STYLUS C79 EPSON STYLUS PHOTO R280 EPSON STYLUS C120 WorkForce 40 WorkForce 30 Artisan 50	EPSON STYLUS PHOTO R340 EPSON Stylus Photo R240 EPSON Stylus Photo R245 EPSON Stylus C45 EPSON Stylus C46 EPSON Stylus C48 EPSON Stylus D68 EPSON Stylus D68 Photo Edition EPSON STYLUS PHOTO R220 EPSON STYLUS PHOTO R360 EPSON STYLUS PHOTO R265 EPSON STYLUS PHOTO R270 EPSON STYLUS D88 EPSON STYLUS D88 Photo Edition EPSON STYLUS D78 EPSON STYLUS PHOTO R285 EPSON STYLUS D120 EPSON STYLUS D92 EPSON STYLUS OFFICE B40W EPSON STYLUS OFFICE B30 EPSON STYLUS S20 Epson Stylus Photo P50 Epson Stylus S21	EPSON STYLUS PHOTO R350 EPSON Stylus Photo R250 EPSON ME PHOTO 20 EPSON ME 1 EPSON ME 1+ EPSON Stylus C67 EPSON STYLUS PHOTO R230 EPSON STYLUS PHOTO R390 EPSON STYLUS PHOTO R270 EPSON ME 2 EPSON STYLUS C110 EPSON ME OFFICE 80W EPSON ME OFFICE 70 EPSON ME 30
複合機	PM-A890 PX-A650 PM-A750 PM-A950 PX-A720 PM-A820 PM-A920 PM-A970 PM-T990 PX-A620 PM-T960 PM-A940 PM-A840 PX-FA700 PX-A740 PX-A640 EP-901F EP-901A EP-801A PX-601F PM-840S PX-501A PX-401A	EPSON Stylus CX4800 EPSON Stylus CX4200 EPSON STYLUS CX5800F EPSON STYLUS CX3800 EPSON STYLUS CX3805 EPSON STYLUS CX3810 EPSON Stylus CX7800 EPSON STYLUS CX6000 EPSON STYLUS CX7000F EPSON STYLUS PHOTO RX580 EPSON STYLUS CX5000 EPSON STYLUS PHOTO RX680 EPSON STYLUS PHOTO RX595 EPSON STYLUS CX9400Fax EPSON STYLUS CX8400 EPSON STYLUS CX7400 EPSON STYLUS CX7400V EPSON STYLUS CX7450 EPSON STYLUS CX4400 EPSON STYLUS CX4450 Artisan 800 Artisan 700 WorkForce 600 EPSON STYLUS NX400 EPSON STYLUS NX100 EPSON STYLUS NX105 EPSON STYLUS NX200 EPSON STYLUS NX300 WorkForce 500 Epson Stylus NX510 Epson Stylus NX515 WorkForce 310 Epson Stylus NX410 Epson Stylus NX415 Epson Stylus NX215 Epson Stylus NX115	EPSON STYLUS PHOTO RX640 EPSON Stylus DX4800 EPSON Stylus DX4850 EPSON Stylus DX4850plus EPSON Stylus DX4200 EPSON Stylus DX4250 EPSON STYLUS DX3800 EPSON STYLUS DX3850 EPSON STYLUS DX3850plus EPSON Stylus Photo RX520 EPSON STYLUS DX6000 EPSON STYLUS DX6050 EPSON STYLUS DX7000F EPSON STYLUS PHOTO RX560 EPSON STYLUS DX5000 EPSON STYLUS DX5050 EPSON STYLUS CX4080 EPSON STYLUS DX4000 EPSON STYLUS DX4050 EPSON STYLUS PHOTO RX685 EPSON STYLUS PHOTO RX585 EPSON STYLUS DX9400F EPSON STYLUS DX9400F WiFi edition EPSON STYLUS DX8400 EPSON STYLUS DX8450 EPSON STYLUS DX7400 EPSON STYLUS DX7450 EPSON STYLUS DX4400 EPSON STYLUS DX4450 EPSON STYLUS PHOTO PX800FW EPSON STYLUS PHOTO PX700W EPSON STYLUS SX600FW EPSON STYLUS OFFICE BX600FW EPSON STYLUS SX400 EPSON STYLUS SX405 EPSON STYLUS SX100 EPSON STYLUS SX105 EPSON STYLUS SX200 EPSON STYLUS SX205 EPSON STYLUS OFFICE BX300F Epson Stylus SX510W Epson Stylus SX515W Epson Stylus Office BX310FN Epson Stylus SX410 Epson Stylus SX415 Epson Stylus SX210 Epson Stylus SX215 Epson Stylus SX110 Epson Stylus SX115	EPSON Stylus CX4700 EPSON STYLUS CX3700 EPSON Stylus Photo RX530 EPSON STYLUS CX5900 EPSON STYLUS CX6900F EPSON STYLUS PHOTO RX590 EPSON ME 200 EPSON STYLUS PHOTO RX690 EPSON STYLUS CX9300F EPSON STYLUS CX8300 EPSON STYLUS CX5500 EPSON STYLUS PHOTO TX800FW EPSON ME OFFICE 700FW EPSON ME 300 EPSON ME OFFICE 360 EPSON ME OFFICE 600F
A3プリンタ	PM-3500C PM-3700C PX-G5000 PX-5500 PX-G5100 PM-G4500 PX-5800 PX-G5300 PX-5600	EPSON Stylus Photo 1280 EPSON STYLUS PHOTO R1800 EPSON STYLUS PHOTO R2400 EPSON STYLUS PHOTO 1400 Epson Stylus NX115 Epson Stylus Pro 3800 EPSON STYLUS PHOTO 1900 Epson Stylus Photo R2880	EPSON Stylus Photo 1290 EPSON STYLUS PHOTO R1800 EPSON STYLUS PHOTO R2400 EPSON STYLUS PHOTO 1400 Epson Stylus Pro 3800 EPSON STYLUS PHOTO 1900 Epson Stylus Photo R2880	EPSON Stylus Photo 1290 EPSON STYLUS PHOTO R1800 EPSON STYLUS PHOTO R2400 EPSON STYLUS PHOTO 1390 Epson Stylus Pro3800 EPSON STYLUS PHOTO 1900 Epson Stylus Photo R2880
大判プリンタ	PX-6550 PX-6250S PX-7550 / PX-7500N PX-7550S PX-9550 / PX-9500N PX-9550S PX-H8000 PX-H10000	EPSON STYLUS PRO 4880 EPSON STYLUS PRO 4450 EPSON STYLUS PRO 7880 EPSON STYLUS PRO 7450 EPSON STYLUS PRO 9880 EPSON STYLUS PRO 9450 Epson Stylus Pro 7900 Epson Stylus Pro 9900	EPSON STYLUS PRO 4880 EPSON STYLUS PRO 4450 EPSON STYLUS PRO 7880 EPSON STYLUS PRO 7450 EPSON STYLUS PRO 9880 EPSON STYLUS PRO 9450 Epson Stylus Pro 7900 Epson Stylus Pro 9900	EPSON STYLUS PRO 4880C EPSON STYLUS PRO 4450 EPSON STYLUS PRO 7880C EPSON STYLUS PRO 7450 EPSON STYLUS PRO 9880C EPSON STYLUS PRO 9450 Epson Stylus Pro 7910 Epson Stylus Pro 9910
A4 ビジネスモデル	Offirio PX-B500 Offirio PX-B300	B-500DN B-300	B-500DN B-300	